



EW7011

en

Manual

www.ewent-online.com

EW7011 USB 3.0 Docking Station for 2.5" and 3.5" SATA hard disks

Table of contents

1.0 Introduction	2
1.1 Functions and features	2
1.2 Packing contents	2
2.0 Connecting a hard disk	3
3.0 Connecting the EW7011 to your computer	3
4.0 Using the EW7011	3
4.1 Preparing the hard disk using Windows XP/Vista	4
4.2 Preparing the hard disk using Windows 7	4
5.0 OTB software	5
5.1 Installing the OTB software	5
5.2 Using the OTB software	5
5.2.1 Using the backup button of the EW7011	5
5.2.2 Making a backup with the PC Clone EX software	6
5.2.3 Restore a backup	6
6.0 Frequently Asked Questions	6
7.0 Service and support	7
8.0 Warning and points of attention	7
9.0 Warranty conditions	8
10.0 Declaration of Conformity	9

1.0 Introduction

Congratulations with the purchase of this high-quality Ewent product! This product has undergone extensive testing by Ewent's technical experts. Should you experience any problems with this product, you are covered by a five-year Ewent warranty. Please keep this manual and the receipt in a safe place.

Register your product now on www.ewent-online.com and receive product updates!

1.1 Functions and features

The EW7011 Docking Station offers you a quick and easy way to connect a 2.5" and/or 3.5" SATA hard disk without having to open the cover of your computer. The EW7011 is equipped with a USB 3.0 port. Thanks to this connection, it is very easy to save and exchange your data. The EW7011 features a smart one-touch backup button which allows you to make a backup of your data.

1.2 Packing contents

The following parts need to be present in the packing:

- EW7011 USB 3.0 Docking Station for 2.5" and 3.5" SATA hard disks
- Power supply
- USB 3.0 cable
- CD-ROM with OTB software
- Manual

2.0 Connecting a hard disk

Use the following steps to mount a hard disk in the EW7011.

1. Make sure the EW7011 is completely turned off.
2. Take your SATA hard disk with the label on top and the SATA connector at the bottom. Make sure the SATA connection is pointed towards the hard disk slot of the EW7011. If correct, the connectors of the EW7011 and hard disk are perfectly aligned.
3. Carefully slide the hard disk into the EW7011. The hard disk will 'click' into its position.

Hint: Do not disconnect the hard disk from the EW7011 while in use. The EW7011 needs to be turned off. This way, damage to both the hard disk and EW7011 can be prevented.

3.0 Connecting the EW7011 to your computer


1. Make sure the hard disk has been mounted as described in chapter 2.
2. Connect the supplied USB cable to the USB connection of the EW7011.
3. Connect the other side of the USB cable to a free USB port on your computer.
4. Connect the cable of the power supply to the 'DC IN' connection of the EW7011.
5. Connect the power supply to a wall outlet.
6. Press the 'Power' button of the EW7011 to turn the EW7011 on.
7. Your computer will automatically detect the hardware of both the EW7011 and the SATA hard disk. If correct, Windows will detect a 'USB Mass storage device'.

Note: USB is 'hot swappable', which means there is no need to turn off your computer while connecting the EW7011 using USB.

4.0 Using the EW7011

The moment Windows has found the hardware and has finished installing this hardware, the EW7011 is ready to be used. If a hard disk has been mounted which has been pre-used, then you are able to use the hard disk to transfer data. However, if the hard disk you have mounted is brand new, and has not been formatted before, you have to prepare the hard disk for usage with Windows. Use the following steps to do so.

Note: Make sure you must safely remove the EW7011 from your computer.

Click 'Safely remove hardware'  icon on the taskbar and you will see a list of devices. Click the device you want to remove.

4.1 Preparing the hard disk using Windows XP/Vista

1. Right click the 'My Computer' icon.
2. Click 'Manage'.
3. Select the option 'Disk Management' from the left side of the screen.
4. Right click the new hard disk and choose 'Initialize'.
5. Click 'OK'.
6. Right click the new hard disk.
7. Click 'New Partition'.
8. Click 'Next'.
9. Click 'Next'.
10. Click 'Next'.
11. Choose the desired partition format (Note: when using FAT32 the partition size is limited to 32GB).
12. Click 'Next'.
13. Select the drive letter you wish to assign to this partition.
14. Click 'Next'.
15. Select the desired file system: FAT32 or NTFS.

Note! If you only use the hard disk on Windows XP or Vista systems we recommend the usage of the NTFS file system. However, If you are also using older Windows systems, we recommend the usage of FAT32.

16. Enter a name for the new partition in the field 'Volume label'.
17. Enable the checkbox near 'Quick format'.
18. Click 'Next'.
19. Click 'Finish'.
20. The hard disk is now ready to be used.

4.2 Preparing the hard disk using Windows 7

1. Go to 'Start'.
2. Select 'Control Panel'.
3. Select 'Administrative Tools'.
4. Select 'Computer Management'.
5. Select 'Disk Management' at 'Storage'.
6. Right-click the new hard disk and click 'New Simple Volume'.

7. Choose the amount of free space needed for the new disk/partition. We recommend to use all of the free disk space.
8. Select the drive letter you wish to assign.
9. Enter a name for the new partition.
10. Format the hard disk.
11. After formatting, the hard disk is ready to be used.

Note: Formatting the hard disk can take a few minutes, depending on the hard disk size. Do not interrupt this process.

5.0 OTB software

The EW7011 is supplied with so called OTB software for Windows. Using this software and the 'One touch Backup' button on the EW7011, you are able to make a backup of your data. You can also select which data needs to be back upped.

5.1 Installing the OTB software

1. Start your computer.
2. Place the installation disk in your CD-rom or DVD-player.
3. The installation disk will start automatically .
4. Choose your language.
5. Choose 'Install OTB software'.
6. Follow the instructions on screen to continue.

Note! When installing this software on Windows Vista or 7, you will be prompted to give permission to continue the installation.

5.2 Using the OTB software

There are two methods to make a backup with the EW7011. You can use the PC Clone EX software to make a backup, or you can use the handy 'Backup button' of the EW7011 itself. In the following examples we will explain how you can use these two methods.

5.2.1 Using the backup button of the EW7011.

1. Press the 'Backup' button of the EW7011 once.
2. The PC Clone EX software will be started.
3. The first time you make a backup, you've to make a selection of the disk(s) and folders you want to backup. At the left side of the screen you can make the desired selection.
4. Press the 'Backup' button once more.
5. The backup will now start.
6. Click 'OK' to confirm that the backup has finished.

5.2.2 Making a backup with the PC Clone EX software

1. Click 'Start'.
2. Click 'Programs'
3. Select 'PC Clone EX'.
4. Click 'PC Clone EX'.
5. Click the second icon in the menu tray (Files Backup).
6. Select at the left column the hard disk and folders you want to backup.
7. Click at the right side of the screen on the first icon called 'Backup'.
8. Click 'Start'. The backup will now start.
9. Click 'OK' to confirm that the backup has finished.

5.2.3 Restore a backup

You can also restore a backup. This is a very convenient function which only alter changed data. There is no need to make a complete backup again.

1. Press the backup button of the EW7011 or click the second icon in the system tray (Files backup).
2. Now, select the desired files and folders you want to backup at the right side of the screen. When selecting the first folder, all the subfolders and directories will be saved in a backup.
3. Click at the right side of the screen on the 'Restore' icon.
4. Click 'OK' to confirm that restoring the backup has finished.

6.0 Frequently Asked Questions

- Q: Is there a disk size limitation for the EW7011?
- A: Disks up-to 2TB have been tested with the EW7011. Note that Windows XP supports hard disks up to 2TB. When using a larger hard drive, you need to create partitions with a maximum size of 2TB.
- Q: What transfer speeds can be obtained using USB?
- A: Using the USB 2.0 port, a data rate of 5 Gbps can be achieved.
- Q: The manual mentions the EW7011 using Windows systems. However, am I able to use the EW7011 on my Mac OS X system?
- A: Since this device is classed as a 'USB Mass Storage' device while connected by USB, it should work fine on Mac OS X. The OTB software has been designed for Windows systems and will not function using Mac OS X.

7.0 Service and support

This users manual has been carefully written by Ewent's technical experts. If you have problems installing or using the product, please fill out the support form at the website www.ewent-online.com.

You can also contact us by phone. Below you will find a list with phone numbers for each supported country.

Country	Phone number	Rate per minute*
Belgium (Dutch)	070 277 286	€0.30
Belgium (French)	070 277 286	€0.30
Denmark	+45 69918565	Local Costs
Finland	+35 8942415826	Local Costs
Germany	(+49) (0)30 887 89 298	Local Costs
Italy	+39 0240042016	Local Costs
Norway	+47 21075033	Local Costs
Spain	807 080 042	€0.41
Sweden	+46 840 309985	Local Costs
The Netherlands	0900-3646368	€0.45
UK	(+44) (0)203 318 9998	Local Costs

* Rates mentioned in this table do not include cell phone charges.

8.0 Warning and points of attention



Due to laws, directives and regulations set out by the European parliament, some (wireless) devices could be subject to limitations concerning its use in certain European member states. In certain European member states the use of such devices could be prohibited. Contact your (local) government for more information about this limitations.

Always follow up the instructions in the manual, especially where it concerns devices which need to be assembled.

Warning: In most cases this concerns an electronic device. Wrong/improper use may lead to (severe) injuries!

Repairing of the device should be done by qualified Ewent staff. The warranty immediately voids when products have undergone self repair and/or by misuse. For extended warranty conditions, please visit our website at www.ewent-online.com

9.0 Warranty conditions

The five-year Ewent warranty applies to all Ewent products unless mentioned otherwise before or during the moment of purchase. When having bought a second-hand Ewent product the remaining period of warranty is measured from the moment of purchase by the product's first owner. The Ewent warranty applies to all Ewent products and parts inextricably connected to and/or mounted on the main product. Power supply adapters, batteries, antennas and all other products not integrated in or directly connected to the main product and/or products of which, without reasonable doubt, can be assumed that wear and tear show a different pattern than the main product are not covered by the Ewent warranty. Products are not covered by the Ewent warranty when subjected to incorrect/improper use, external influences and/or when opened by parties other than Ewent.

10.0 Declaration of Conformity

To ensure your safety and compliance of the product with the directives and laws created by the European Commission you can obtain a copy of the Declaration of Conformity concerning your product by sending an e-mail message to: info@ewent-online.com. You can also send a letter to:

Ewent Europe, PO Box 276, 6160 AG Geleen, The Netherlands.
Ewent Italy, Crocevia 12, 39057 Appiano (BZ), Italy

Clearly state 'Declaration of Conformity' and the article code of the product of which you would like to obtain a copy of the Declaration of Conformity.

EW7011 | 12-2012

e'went
by eminent

www.ewent-online.com

Trademarks: all brand names are trademarks and/or registered trademarks of their respective holders.
The information contained in this document has been created with the utmost care. No legal rights can be derived from these contents. Eminent cannot be held responsible, nor liable for the information contained in this document.



Ewent is a member of the Eminent Group